


# POWER-I & POWER-II BATTERY BACK-UP



- ü PROVIDES FULL SYSTEM BACK-UP POWER
- ü FULLY OPERATIONAL BATTERY BACK-UP

CYCLE CHART	EAGLE GATE OPERATOR	APPROXIMATE GATE TRAVEL	AVERAGE CYCLES PER 12 HOUR PERIOD	ADDITIONAL CYCLES WITH EXTRA BATTERY
	<b>SLIDE GATE OPERATORS</b>			
	EAGLE-I	10'	160	320
		15'	110	220
	EAGLE-1000 (FSF OR FSC)	15'	140	280
		20'	100	200
		20'	70	140
	EAGLE-2000 (FSF OR FSC)	10'	120	240
		15'	80	160
		20'	50	100
	EAGLE-2000-DM	10'	120	240
		15'	80	160
		20'	50	100
	<b>SWING GATE OPERATORS</b>			
	EAGLE-II	0°-90°	140	280
EAGLE-100	0°-90°	120	240	
EAGLE-200	0°-90°	100	200	
EAGLE-200-DM	0°-90°	100	200	
	<b>SLIDE GATE OPERATORS</b>			
	EAGLE-2000-1HP	10'	80	160
		15'	50	100
		20'	30	60
	EAGLE-2000-APT	10'	80	160
		15'	50	100
		20'	30	60
	EAGLE-2000-APT-1.5HP	10'	60	120
		15'	40	80
		20'	20	40
	EAGLE-2000-APT-DM	10'	80	160
		15'	50	100
		20'	30	60
	<b>SWING GATE OPERATORS</b>			
EAGLE-200-1HP	0°-90°	70	140	

Dimensions:	Power-I 12-3/8" (H) x 17-1/2 (W) x 12-3/8" (D) Weight 85 lbs	Power-II 13-3/8" (H) x 21" (W) x 10-7/8" (D) Weight 90 lbs Second Battery Compartment 8-3/4" (H) x 16" (W) x 12-1/2" (D) Weight 65 lbs
-------------	--	---

**Note:**

1. Operating Cycles are estimates and may vary based on your conditions.
2. All ratings are for operator including Diamond Control Board, 2 Loop Detectors, Receiver, MAG Lock, Telephone Entry System and 1 Photo Detector. Additional accessories will reduce number of cycles.
3. Surge Protection on incoming 110V AC recommended.
4. Eagle Power-I and Power-II warranted 1-year. No warranty when used with a non-Eagle Operator.

Eagle Access Control Systems, Inc.  
13286 Paxton Street  
Pacoima, CA 91331

Toll Free: 800-708-8848  
Fax: 818-899-2666  
www.EagleOperators.com